

# **Selective Level Meter**



### **Features**

- Digital Synthesized Local Oscillator
- ★ Two Selective Bandwidths: 20Hz. 3.1KHz
- Wideband, Low Noise and Low Distortion Measurements
- ★ dB/dBm Operation
- ★ High Frequency Stability
- ★ Internal Calibration Facility
- \* Recorder Outputs

- ★ Frequency Tracking Facility with Level Oscillator SLG620
- ★ Storage of Nine Spot Frequencies
- Reference Level Set Facility
- Autotune Feature
- ★ Operates on AC Mains or Internal Rechargeable Battery
- ★ Built in charger
- ★ Graphic LCD Display with Backlight

## **Application**

Aplab SELECTIVE LEVEL METER Model SLM620 and LEVEL OSCILLATOR Model SLG620 forms a measuring set covering frequencies from 200Hz to 620KHz for the measuring of carrier frequency systems. Its compactness and light weight as well as the versatile power-supply makes the SELECTIVE LEVEL METER suitable for use in places where no mains is available (e.g. measurements of remote supplied repeater stations, PLCC installation & servicing).

The SELECTIVE LEVEL METER (Low Noise & Low Distortion modes) is equally suitable for wide-band and selective measurements. The adapter supplied as an accessory allows impedance, balance attenuation and return loss measurements.

Wide frequency range and sensitivity range of the SELECTIVE LEVEL METER allows the measurement of transmission characteristics as well as crosstalks and other interference signals.

The selective level meter has two filters:

- a wide band filter with an effective bandwidth of 3.1KHz for noise measurements.
- a narrow band filter with a bandwidth of 20Hz for the measuring of carrier leak, crosstalk and non-linear distortion.

The facility to set the reference at currently read level and storage for nine frequency spots are provided. AUTOTUNE feature will capacitate the user to find the peak near the center frequency automatically.

### **Specifications**

**INPUTS** 

**Balanced** : 200Hz to 620KHz. **Unbalanced** : 50Hz to 620KHz.

**INPUT IMPEDANCES** 

**Terminated Input** : 75, 125, 150, 600 Ohm.

 Unterminated Balanced Input

 10KHz to 300KHz
 : ≥8 Kohm.

 300Hz to 620KHz
 : ≥5 Kohm.

 200Hz to 300Hz
 : ≥3.5 Kohm.

Unterminated

Unbalanced Input : ≥10 Kohm // 60pF.

Balance of Input : ≥40 dB.

**OUTPUTS** 

DC Output (Recorder) : 150mV across 2.5K ohms

at 0dB meter deflection.

AC Output (Recorder) : -20dB, 600 ohms at 0dB

meter deflection.

WIDE BAND LEVEL MEASUREMENT

Frequency Range : 50Hz to 620KHz

(usable upto 650KHz).

Sensitivity in Steps of 10 dB

Balanced Input : -60 to +40dB/dBm.
Unbalanced Input : -70 to +30dB/dBm.

Min. Readable Level : Approx. -80dB/dBm.

LEVEL MEASUREMENT ACCURACY

At 0 dB level at the :  $\leq \pm 0.1$  dB.

0 scale division after calibration at 20KHz

Attenuator Error Referred

To the 0 dB range :  $\leq \pm 0.1$  dB.

at 20KHz

Additionally in the :  $\leq \pm 0.1$  dB.

most Sensitive range

**SELECTIVE MEASUREMENT** 

Frequency Range : 200 Hz to 620 KHz (continuously without (usable upto 650KHz).

band changeover)

Frequency Settings : Manually coarse & fine,

continuously adjustable with  $\triangle$  &  $\nabla$  key or rotary knob.

Automatic Tuning : Automatic tracking between (synchronisation) level meter and generator is

provided.

**SELECTIVITY** 

		Narrow	Wide
Pass Bandwidth	∆a <u>&lt;</u> 0.5dB	±4Hz	±800Hz
Bandwidth	∆a=3dB	≈20Hz	≈3.1KHz
Stop Band Attn.	∆a <u>&gt;</u> 30dB	±80Hz	
Stop Band Attn.	∆a≥50dB		±10KHz
Stop Band Attn.	∆a <u>&gt;</u> 60dB	±500Hz	

Image Frequency: ≥70 dB for  $f_m + 2f_{i1}$ Rejection~80dB for  $f_m + 2f_{i2}$ 

Dynamic Measurement: 70dB.

Range

Sensitivity in steps of 10 dB

Band-	Mode	Frequency	Input	
width		Range/KHz	Unbalanced	Balanced
20Hz	Low	0.2 to	-120 to	-110 to
	Distortion	620KHz	+30dB/dBm	+40dB/dBm
	Low	0.2 to	-100 to	-90 to
	Noise	620KHz	+30dB/dBm	+40dB/dBm
3.1KHz	Both	10 to	-100 to	-90 to
	Modes	620KHz	+30dB/dBm	+40dB/dBm

Min. Readable Level : Approx. -125dB (20Hz BW unbal low distortion mode).

Approx. -110dB (20Hz BW unbal low noise mode).

LEVEL MEASUREMENT ACCURACY

At 0 dB level, at the :  $\leq \pm 0.1$ dB.

0 Scale Division after calibration at 100KHz

Frequency Response related to 20KHz 1 to 200KHz :  $\leq \pm$  0.1dB. 0.2 to 620KHz :  $\leq \pm$  0.15dB. Attenuator error : <0.1dB.

referred to the 0dB range at 100KHz

Additionally in Balanced Mode In the range -100dB : 0.2dB

-110dB : 0.8dB

Additionally in Unbalanced Mode In the range -110dB : 0.2dB. -120dB : 0.8dB.

Operating Time : Continuously.

**RETURN LOSS / IMPEDANCE MEASUREMENT** 

(Optional Attachment SLM620-1)

**IMPEDANCE** 

Impedance Range : 300Hz to 620KHz.

Measurement Range : 50 to 3000 ohm.

Measurement Accuracy : ±10% (upto 300KHz)
±20% (300KHz to 620KHz).

**BALANCE & RETURN LOSS** 

Frequency Range : 300Hz to 620KHz.

Impedance Limit : 60 ohms to 1200 ohms.

Balance or Return : 40dB max.

**Loss Measurement** 

**Accuracy**: ±1dB (upto 300KHz)

±2dB (300KHz to 620KHz).

Balance Measurement : At 600, 150, 125 & 75 ohms.

**GENERAL SPECIFICATIONS** 

Display : 128 x 64 Graphic LCD

with Backlit.

Resolution : 0.01dB with 5 digit display.

Frequency Resolution : 1Hz with 6 digit display

(upto 100KHz cursor settable).

: 330 (W) x 165 (H) x 435 (D)

Frequency Accuracy : 1 x 10<sup>-5</sup> ±1 digit at 27°C.

Frequency Stability : 10 ppm/°C.

Power (Mains) : 230V AC ±15%, 50Hz ±5%,

14VA.

Battery Operation : Built-in rechargeable battery

provided.

Battery Charging : Built-in charger.
Battery Consumption : 6V / 0.8A
Battery Backup : 3 Hrs.

Battery Backup : 3 Hrs.
Battery Type : 6V, 4AH SMF Battery.

approx.

Weight : 11.5 Kg approx.

STANDARD ACCESSORIES

**Dimension** 

a) 3-core Power Cord - 1 No.

b) 2-core External Battery Connector with Jack - 1 No.

c) 3 Pin to 3 Pin Cable - 1 No.d) BNC to BNC Cable - 1 No.e) Instruction Manual - 1 No.

f) Carrying Case - 1 No.

**OPTIONAL ACCESSORIES** 

 a) Return Loss & Impedance Measurement Accessory (SLM620-1) - 1 No.

b) Carrying Case - 1 No.

WE PURSUE A POLICY OF CONTINUOUS DEVELOPMENT AND PRODUCT IMPROVEMENT. THUS THE SPECIFICATIONS IN THIS DOCUMENT AND THE LOCATION OF CONTROLS ON THE FRONT PANEL MAY BE CHANGED WITHOUT NOTICE.



## **Test & Measurement Instruments**

#### **APLAB LIMITED**

APLAB HOUSE, A-5, WAGLE ESTATE, THANE 400 604. INDIA. TEL: +91-22-67395555, 25821861 FAX: 25823137 EMAIL: tmisales@aplab.com WEBSITE: www.aplab.com

• BANGALORE Tel.: 080-23576001 to 07 Fax: 23576008 E-mail: aplabblr@aplab.com

• CHENNAI Tel.: 044-26680472, 26680477 Fax: 26680473 Email: aplabchn@aplab.com

• KOLKATA Tel.: 033-22455435, 22848834 Fax: 22454294 Email: aplabcal@aplab.com

• MUMBAI Tel.: 022-29201787, 29204642, 29203468 Fax: 29209066 Email: aplabwr@aplab.com

NEW DELHI Tel.: 011-23515183/86, 23627467 Fax: 23634709 Email: aplabnd@aplab.com
 SECUNDERABAD Tel.: 040-27811012, 27843351, 27720339 Fax: 27897788 Email: aplabsec@aplab.com